# OnePak 8 +22G (Article number: BC000394)

[va-Q-one 8 +22G]

For +15 °C to +25 °C shipments





Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

### **DESCRIPTION**

Specifically designed for door-to-door pharmaceutical distribution of smaller volumes to remote locations, OnePak ensures your products reach even the most inaccessible areas without compromising quality or efficacy. This single-use solution is ideal for regions with limited logistics services, eliminating the need for return shipping and ensuring consistent access to medicines.

Date: 2024-08-21 Page: 1 of 2 Version: 14405

## OnePak 8 +22G (Article number: BC000394)

[va-Q-one 8 +22G]

For +15 °C to +25 °C shipments



#### **DIMENSIONS AND WEIGHT**

External Dimensions (1 x w x h)		Internal Dimensions <sup>1</sup> (l x w x h)		Tolerances	
[ mm ]	[inch]	[ mm ]	[inch]	[ mm ]	[inch]
380 x 360 x 375	15 x 14.2 x 14.8	200 x 200 x 200	7.9 x 7.9 x 7.9	± 5	± 0.2

Tare W	eight <sup>1</sup>	Payload <sup>1</sup> (Volume)	
[kg]	[lbs]	[L]	
9.7 ± 1	21.4 ± 2.2	8	

<sup>1</sup>including Temperature Batteries

#### TEMPERATURE BATTERY CONFIGURATION

	OneBlok	Pieces	Dimensions <sup>2</sup> (1 x w x h)		Weight		Material number
OHODIOK	1 10003	[ mm ]	[inch]	[kg]	[lbs]	Haterial Hamber	
	23233 +22G	6	225 x 225 x 29	8.9 x 8.9 x 1.1	1.2	2.6	AK000233

<sup>&</sup>lt;sup>2</sup>dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

#### PERFORMANCE The OnePak 8 +22G is qualified in the temperature range from +15 °C to +25 °C

Temperature scenario	Duration [hrs]	Kelvin-hours <sup>3</sup>	Average ambient temperature [°C]
ISTA 7D summer	≥ 131	≥ 1302	+29.9
ISTA 7D winter	≥ 107	≤ -1562	+5.4

<sup>&</sup>lt;sup>3</sup>Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the OnePak 8 +22G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.