OnePak 74 +05G (Article number: BC000428)

[va-Q-one 74 + 05G]

For +2 °C to +8 °C shipments





Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

DESCRIPTION

Specifically designed for door-to-door pharmaceutical distribution of smaller volumes to remote locations, OnePak ensures your products reach even the most inaccessible areas without compromising quality or efficacy. This single-use solution is ideal for regions with limited logistics services, eliminating the need for return shipping and ensuring consistent access to medicines.

Date: 2024-08-21 Page: 1 of 2 Version: 14400

OnePak 74 +05G (Article number: BC000428)

[va-Q-one 74 + 05G]

For +2 °C to +8 °C shipments



DIMENSIONS AND WEIGHT

External Dimensions (1 x w x h)		Internal Dimensi	ions ¹ (1 x w x h)	Tolerances	
[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
595 x 585 x 585	23.4 x 23 x 23	420 x 420 x 420	16.5 x 16.5 x 16.5	± 5	± 0.2

Tare W	eight ¹	Payload ¹ (Volume)		
[kg]	[lbs]	[L]		
26.4 ± 1	58.2 ± 2.2	74		

¹including Temperature Batteries

TEMPERATURE BATTERY CONFIGURATION

ProofBlok	Pieces	Dimensions ² (1 x w x h)		Weight		Material number
		[mm]	[inch]	[kg]	[lbs]	TIG COTTAL TIGINOOT
46462 +05G	6	455 x 455 x 20	17.9 x 17.9 x 0.8	3.1	6.8	AK000159

²dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

PERFORMANCE The OnePak 74 +05G is qualified in the temperature range from +2 °C to +8 °C

Temperature scenario	Duration [hrs]	Kelvin-hours ³	Average ambient temperature [°C]
ISTA 7D summer	≥ 120	≥ 3049	+30.2
ISTA 7D winter	> 144	n.a.	+4.8

³Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the OnePak 74 +05G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.