ProofTainer 2 US -21G

[va-Q-tainer TWINx -21G]

For -25 °C to -15 °C shipments





Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

DESCRIPTION

Delivering superior performance while streamlining handling, the ProofTainer family features six sizes, accommodating from 0.5 – 2 EU or 1 - 2 US pallets. Whether you're shipping clinical trials or commercial drugs, we ensure consistent temperature control throughout your products journey. With qualified temperature ranges from -70°C to +20°C and over 120 hours of autonomy, ProofTainer provides optimal conditions for your sensitive cargo, delivering the flexibility you need for your product requirements.

Date: 2024-08-21 Page: 1 of 2 Version: 14751

ProofTainer 2 US -21G

[va-Q-tainer TWINx -21G]

For -25 °C to -15 °C shipments



DIMENSIONS AND WEIGHT

External Dimensions (1 x w x h)		Internal Dimensi	$ons^1 (1 \times w \times h)$	Tolerances	
[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
2380 x 1490 x 1580	93.7 x 58.7 x 62.2	2110 x 1250 x 1220	83.1 x 49.2 x 48	± 8	± 0.3

Tare Weight ¹		Volumetric weight		Maximum Payload (Weight)		Payload ¹ (Volume)
[kg]	[lbs]	[kg]	[lbs]	[kg]	[lbs]	[L]
910 ± 20	2006.2 ± 44.1	934	2059.1	1200	2645.5	3200

¹including Temperature Batteries

TEMPERATURE BATTERY CONFIGURATION

ProofBlok	Pieces	Dimensions ² (1 x w x h) [mm] [inch]		Weight [lbs]		Material number
27L -21G	76	470 x 275 x 32	18.5 x 10.8 x 1.3	4.3	9.5	AK000033

²dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

PERFORMANCE The ProofTainer 2 US -21G is qualified in the temperature range from -25 °C to -15 °C

Temperature scenario Duration [hrs]		Kelvin-hours ³	Average ambient temperature [°C]	
regular summer	≥ 136	≥ 6773	+29.8	
extreme summer	83	n.a.	+49.3	

³Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the ProofTainer 2 US -21G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.